Index

breeze penetration 8-9, 14f, 17

computational fluid dynamics 23–24, 37*f*, 40–42

dispersion modeling: in boundary layer wind tunnels 22; with computational fluid dynamics 23–24, 37*f*

field studies 42–43 flow visualization 38, 43*f*, 44*f*

heat islands 8–9, 14*f* high-rise office buildings 18–19, 23*t*, 32*f*, 33*f* hurricane shelters. *see* storm shelters

natural ventilation: of high-rise office buildings 18–19, 23*t*, 32*f*, 33*f*; of lowrise buildings 19–20, 34*f*, 35*f*; outdoor human comfort 20–21, 36*f*; for urban development 9

pedestrian level winds 6-8, 13f, 16-17,

28f, 29f, 30f

storm shelters 15–16, 25f, 26f, 27f, 28f

tornado shelters. *see* storm shelters town planning 6, 12*f*

urban aerodynamics: elements of 2; tools and techniques 3; wind engineering in 2–3 urban planning 5, 6–9, 10*f*, 11*f*, 12*f*, 13*f*, 14*f* urbanization trends 4*t*

wind effects 38, 45*f* wind power 23 wind shielding 17–18, 30*f*, 31*f* wind tunnels: dispersion modeling in 22; measurements in 39–40, 47*f* winds: breeze penetration 8–9, 14*f*; heat islands 8–9, 14*f*; natural ventilation 9, 14*f*; pedestrian level 6–8, 13*f*, 16–17, 28*f*, 29*f*, 30*f*; wind shielding 17–18, 30*f*, 31*f*